




BOOST CONTROL SOLENOID

**3-WAY NORMALLY OPEN
VALVE CONFIGURATION**



Port 1 – Normally Closed
Port 2 – Common
Port 3 – Normally Open